




TECHNICAL INFORMATION

MODEL: EXPEDITION 500

DIAGRAM: RESET & MANUAL BODY LIFT



BODY LIFTING COMPUTER LOCATED UNDERNEATH THE SEAT ON THE LEFT SIDE OF THE TRAILER. HAND CONTROL LOCATED IN THIS LOCATION. FIRST DO STEP 1) 3 SECONDS RESET THE COMPUTER. IF THIS DOES NOT WORK UNPLUG LEGS AND REPLUG INTO CONTROL BOARD AND MANUALY CONTROL. CONTACT TRIBE FOR ASSISTANCE WHEN IN A SECURE LOCATION.